



Oracle Rack Series

RACK MOUNT INTELLIGENT LCD LOOP DETECTOR

Oracle detectors indicate vehicle presence with great accuracy and reliability, and incorporate a complete built-in loop analyzer for optimum detector set-up and loop diagnostics.

FEATURES

- LCD View Screens
- DEFLECTOMETER® Pie Graph & Numeric Value Indicator
- DEFLECTOMETER® Streaming Graph
- Frequency Stability Graph
- Directional Logic and 3rd Car Logic
- Loop Fault History Log
- Loop Inductance Display Indicator

HIGHLIGHTS

- - Δ L/L Percentage Indicator
- LCD Display Back Lighting and Heater
- Variable Character Channel ID
- Rail Mode (Model 2EC)
- Point Probe Micro Sensor Support (Model 2EC)
- AccurateCount Mode (Model 2EC)
- Communications Port (ECX Models)



LCD View Screens: The Loop Frequency, $-\Delta$ L/L%, Loop Inductance, DEFLECTOMETER® Pie Graph, DEFLECTOMETER® Numeric Optimizer, DEFLECTOMETER® Streaming Graph, Frequency Stability Graph, Sensitivity Level, Mode of Operation, and Vehicle Counting Accumulator can be viewed on the front panel LCD for each channel simultaneously.

DEFLECTOMETER® Pie Graph & Numeric Value Indicator: The LCD screen displays a pie graph which assists in determining the optimum sensitivity setting by showing the change in inductance caused by traffic moving over the loop. Changes to the sensitivity setting are reflected on the graph in real time during a Call state. Optimum sensitivity setting is reached when the DEFLECTOMETER® value reaches the value of 10 or 50% of the graph, based on typical size vehicles. Changes are reflected during the Call, so sensitivity can be (re)adjusted while a vehicle is stopped over the loop. Selecting the optimum sensitivity level insures detection of all vehicles, including motorcycles and hi-bed trucks. This helps to eliminate any further service calls to adjust detector sensitivities.

DEFLECTOMETER® Streaming Graph: While the DEFLECTOMETER® pie graph displays an instantaneous indication of the current Call strength, the Streaming Graph display graphically shows the Call strength over time. The horizontal axis represents a six second interval. The vertical axis represents Call strength. The graph only streams when there is a Call present and displays approximately six seconds of data.

Frequency Stability Graph: The frequency stability graph provides the capability to analyze each frequency level to ensure proper selection of the nominal loop tuning frequency. The XY graph displays detector frequency samples with respect to the reference. A variation from the center of the graph depicts frequency instability on the channel. Basically a thin smooth graph offers a more optimum frequency selection over a thick uneven line.

Paired Channel Functions Directional Logic & 3rd Car Logic: Directional Logic is intended to be used in freeway ramps for wrong way detection and left turn lanes where other



movements in the intersection tend to clip the detection zone of the left turn lane. A Directional Logic setting can be enabled by selecting the "Direction" option in the "Paired Channels" menu. Directional logic mode links ch. 1 and 2 together, and links ch. 3 and 4 together.

3rd Car Logic provides a Call output when both channels are in the Call state. 3rd Car Logic is typically used in left turn queues to provide logic for Protected-Permissive movements. A "3rd Car" mode setting can be enabled by selecting the "3rd Car" option in the "Paired Channels" menu. "3rd Car" mode links ch. 1 and 2 together, and links ch. 3 and 4 together.

AccurateCount Mode (Model 2EC): AccurateCount mode produces a secondary output in addition to the primary CALL output for each vehicle entering the loop zone. Loop configurations ranges from a single loop to eight loops connected together in series. The LCD screen will report counts from the secondary "Count" outputs.

If AccurateCount (Enable Vehicle Counting) mode is enabled, the LCD will report vehicle accumulated counts. For each channel, when a vehicle occupies the loop zone, the LCD counter accumulates one vehicle count per output. The counter is capable of accumulating 999,999 vehicle counts per channel before rolling over to zero.

For each channel of the Oracle 2EC model, the AccurateCount (Enable Vehicle Counting) output feature can be enabled via the "Set up" menu to produce a secondary output in addition to the primary CALL output for every vehicle entering the loop zone. Each vehicle entering the loop will cause an output pulse of 125ms ± 25ms from the secondary "Count" output on pin S [(Channel 1) and pin Y (Channel 2) Model ORACLE 2EC only] irrespective of the size of the loop. For each channel, when the AccurateCount (Enable Vehicle Counting) feature is enabled, a loop configuration must be selected, via the "Set up Counting Type" menu for either a single loop or up to eight loops connected together in series.

Communications Port: The 2ECX, 4ECX, and 4HCX models provide an EIA-232 port for external or remote communications using an advanced protocol to monitor and configure all aspects of the Oracle.

Loop Fault History Log: For each channel, the LCD screen can display the last 25 loop fault conditions and power events.

Loop Inductance Display Indicator: In the "Induct" display mode the LCD screen displays the equivalent system loop inductance (loop and lead-in inductance) within the range of 20 to 2500 microHenries.

-ΔL/L Percentage Indicator: The "Induct" display mode shows the percentage of inductance change during the CALL state.

LCD Display Back Lighting and Heater: The Liquid Crystal Display (LCD) incorporates a white LED backlight. The backlight improves visibility in poor lighting conditions. A built-in heater improves operation in very cold temperatures.

Variable Character Channel ID: With Up to five characters or numbers can be selected to identify each channel of detection.

Rail Mode (Model 2EC): Following Provides a Rail Mode for use with light rail applications to prevent lock-ups on loops deployed under rails.

Point Probe Micro Sensor Support (Model 2EC): Supports the use of point probe type micro sensors. Consult the factory for

compatibility details.

Front Panel Controls: Two high-reliability sealed front panel toggle switches for each channel are used to select operational and display settings. One switch is designated "MENU (Back/Select)" and is used to accept the setting displayed and to move to the next menu item or go back to the previously displayed screen. The second switch is designated "SCROLL (Up/Down)" and allows you to move through each selected menu.

Sensitivity: There are 20 selectable sensitivity levels per channel. The DEFLECTOMETER Pie Graph, DEFLECTOMETER Numeric Value and a DEFLECTOMETER Streaming Graph, make it easy to set-up and optimize sensitivity for each channel. Sensitivity can be selected from the "Set up" or "QuikSet" menus, to optimize vehicle detection on varying loop and lead-in configurations. Sensitivity is stated in terms of -ΔL/L [i.e. as the minimum percentage change in the total inductance (loop plus lead-in) to which the unit will respond at the given level.]

Sens.	-ΔL/L	Sens.	-ΔL/L
20	0.0035%	10	0.113 %
19	0.0050%	9	0.160 %
18	0.0071%	8	0.226 %
17	0.010 %	7	0.320 %
16	0.0141 %	6	0.453 %
15	0.020 %	5	0.640 %
14	0.028 %	4	0.905 %
13	0.040 %	3	1.280 %
12	0.057 %	2	1.810 %
11	0.080 %	1	2.560 %

Loop Frequency: The LCD screen displays the actual loop frequency to help avoid interference which may occur when loops connected to different detectors are located adjacent to one another. One of eight (8) settings (normally in the range of 20 to 60 kilohertz) may be selected for each channel via the "Setup" or the "QuikSet" menu options. It is recommended that adjacent loops have a frequency separation of at least 5 KHz.

Presence / Pulse Modes: For each channel, a Presence or Pulse output mode may be selected via the "SET UP" menu. If presence mode is selected then a choice of short, long, or user defined presence can be selected. Short Presence is defined as 30 minutes and Long Presence is defined as 120 minutes. In User Defined mode, a setting between 1 and 120 minutes can be entered. On the expiration of short or long presence time a detect CALL will be reset. In user defined mode, the detect CALL can be selected to reset on timer expiration or at the next End-Of-Green (EOG) signal after the expiration of the timer. The green signal is applied to the Timer Control input via the edge card connector. In Pulse mode, a 125 ms ± 25ms width pulse will be output for each vehicle entering the loop.

Event Log: For each channel, the LCD screen can display the last 25 loop fault conditions and power events via the "Event Log" menu. A channel reset will not clear the Event Log from memory. To clear the Event Log memory, select either "Clear Log" or "Clear All" from the "Event Log" menu.

Call Delay Timer: For each channel, a delay time of 0.1 seconds

Specifications subject to local environmental conditions, and may be subject to change. All Eberle Design LLC. products are Designed, Manufactured and Tested in the United States of America in facilities that are certified to ISO quality standards. DEFLECTOMETER, "Eberle Design Inc." and Eberle Design LLC. logo are trademarks of Eberle Design Inc. © 2024, Eberle Design LLC. Document: EDI_DATA_Oracle-Rack-Series_RevA

to 5 minutes can be set via the "SET UP" menu. Call Delay time starts counting down when a vehicle enters the loop detection area. Delay time can be overridden by a green signal at the Timer Control input.

Call Extension Timer: For each channel, an extension time of 0.1 seconds to 1 minute can be set via the "SET UP" menu. Call Extension time starts counting down when the last vehicle clears the loop detection zone. Any vehicle entering the loop detection zone during the Extension time period causes the channel to return to the CALL state. The Extension timer can be enabled upon the following options: Extend Always Mode, Extend On-Green Mode, Extend Disconnect, and Extension Plus Disconnect.

Timer Control Inputs: Timer Control inputs are provided for each channel to modify the operation of the Delay and Extension functions. The application of a True (low) state voltage will inhibit the Delay timing function and/or enable the Extend timing function. Timer Control inputs are primarily provided for downward compatibility.

Channel Output Control: Each channel has one of three output options to choose from in the Setup menu; OFF, ON, or CALL.

Loop Fault Monitor: The detector continuously checks the integrity of the loop. The system is able to detect open circuit loops, shorted loops, or sudden changes in inductance exceeding 25% of the nominal inductance. If a fault is detected, both the DETECT (Red) and FAULT (Yellow) LEDs continuously emit a sequence of flashes. Each type of fault is identified by a different flash sequence. In addition to the LED flash sequence, the LCD will display the type of fault condition during the fault state. If the fault condition is removed, the LCD "Fault" indication and the DETECT (Red) LED will return to normal operation. The FAULT (Yellow) LED will continue to flash with the sequence signifying the type of fault that was last detected. In the case of the 25% Change in Inductance fault (possible loss of a loop within a parallel of loops), the unit will log the fault and return to the new inductance after a period of two seconds. The logged fault will be stored in the Event Log memory. The backlight improves visibility in poor lighting conditions.

High Intensity Color-Coded LED Indicators: Red DETECT Indicator: Vehicle Detection = Solid ON. Delay Timing = 2 Hz flash rate. Extension Timing = 4 Hz flash rate. 3rd Car Mode = 10 flashes per second. Directional Logic Mode = 10 flashes per second. Open Circuit = 1 single flash followed by a pause. Shorted Circuit = 2 flashes followed by a pause. 25% Change in Inductance = 3 flashes followed by a pause.

Yellow FAULT Indicator: Open Circuit = 1 single flash followed by a pause. Shorted Circuit = 2 flashes followed by a pause. 25% Change in Inductance = 3 flashes followed by a pause.

Mechanical: Height = 4.5 inches (114.3 mm). Depth = 6.875 inches (174.6 mm). Width = 1.14"W (28.96mm) 2E, 2EC, & 4H, and 2.34 inches (59.44 mm) 4E.

Environmental: Operating Temperature: -30 to +165°F (-34 to +74°C). LCD Operating Temperature: -4 to 165°F (-20 to +70°C). Humidity Range (non-condensing): 0 to 95% Relative.

Electrical: DC Supply Voltage = 10.8 Vdc to 28.8 VDC. DC Supply Current = 100 mA maximum (2E, 2EC), 175 mA maximum (4E, 4H). DC Supply Heater Current = 250 mA maximum (2E, 2EC,4H), 500 mA maximum (4E). DC Inputs: True (low) = Less than 8 VDC. False (high) = Greater than 16 VDC.

Optically Isolated Outputs: True (low, 50 mA) = Less than 1.5 VDC. False (high) = Greater than 16 VDC. Maximum Current = 100 mA.

Loop Inductance (Tuning) Range: The detector will automatically tune to a loop and lead-in combination within the tuning range of 20 to 2500 microHenry with a Q factor greater than 5.

Environmental Tracking: The detector automatically and continuously compensates for component drift and environmental effects throughout the tuning range and across the entire temperature range.

Grounded Loop Operation: Each detector channel will operate when connected to poor quality loops including those that have a short to ground at a single point.

Lead-in Length: The unit will operate with lead-in (feeder) lengths up to 5,000 feet (1,524 m.) with appropriate loops and proper lead-in cable.

Loop Input Transient Protection: The loop input incorporates transient protection devices and the loop oscillator circuitry is transformer-isolated for each channel. The transient protection will withstand the discharge of a 10 uF capacitor charged to 2,000V across the loop inputs or between a loop input and Earth Ground for each channel. The transformer isolation allows operation with a loop which is grounded at a single point.

Response Timing: Two channel operation with both channels at same sensitivity, Filter Off.

Sens.	Response	Sens.	Response
20	59-104 ms	10	4-7 ms
19	43-76 ms	9	4-7 ms
18	32-55 ms	8	4-7 ms
17	24-41 ms	7	4-7 ms
16	16-28 ms	6	4-7 ms
15	12-21 ms	5	4-7 ms
14	12-21 ms	4	4-7 ms
13	8-14 ms	3	4-7 ms
12	8-14 ms	2	4-7 ms
11	8-14 ms	1	4-7 ms

Connector Pin Assignment: Note: Pins M & N and 11 & 12 are RESERVED

Pin	ORACLE 2E, 2EC	Pin	ORACLE 2E, 2EC
A	Logic Ground	1	Ch 1 Timer Control Input
B	DC Supply	2	Ch 2 Timer Control Input
C	Ext. Reset	3	Det. Address Bit #3
D	Ch 1 Loop Input	4	Ch 1 Redundant Loop Input
E	Ch 1 Loop Input	5	Ch 1 Redundant Loop Input
F	Ch 1 Output (+)	6	Det. Address Bit #0
H	Ch 1 Output (-)	7	Ch 1 Status Output
J	Ch 2 Loop Input	8	Ch 2 Redundant Loop Input
K	Ch 2 Loop Input	9	Ch 2 Redundant Loop Input

Specifications subject to local environmental conditions, and may be subject to change. All Eberle Design LLC. products are Designed, Manufactured and Tested in the United States of America in facilities that are certified to ISO quality standards. DEFLECTOMETER, "Eberle Design Inc." and Eberle Design LLC. logo are trademarks of Eberle Design Inc. © 2024, Eberle Design LLC. Document: EDI_DATA_Oracle-Rack-Series_RevA

Pin	ORACLE 2E, 2EC	Pin	ORACLE 2E, 2EC
L	Chassis Ground	10	Det. Address Bit #1
P	Reserved	13	Reserved
R	Reserved	14	Reserved
S	Ch 1 Cnt Output (+)	15	Det. Address Bit #2
T	Ch 1 Cntt Output (-)	16	Reserved
U	Reserved	17	Reserved
V	Reserved	18	Reserved
W	Ch 2 Output (+)	19	Data Trans. Output (TX)
X	Ch 2 Output (-)	20	Ch 2 Status Output
Y	Ch 2 Cnt Output (+)	21	Data Receive Input (RX)
Z	Ch 2 Cnt Output (-)	22	Reserved

Model Options

Model	Feature
2E	Dual Channel
2EC	AccurateCount Mode
4E	Quad Channel
4H	Quad Channel 1/2 Width
ECX Series	Remote Communications

Pin	ORACLE 4E,4H	Pin	ORACLE 4E,4H
A	Logic Ground	1	Ch 1 Timer Control Input
B	DC Supply	2	Ch 2 Timer Control Input
C	Ext. Reset	3	Det. Address Bit #3 Ch 3 Timer Control Input
D	Ch 1 Loop Input	4	Ch 1 Redundant Loop Input
E	Ch 1 Loop Input	5	Ch 1 Redundant Loop Input
F	Ch 1 Output (+)	6	Det. Address Bit #0
H	Ch 1 Output (-)	7	Ch 1 Status Output
J	Ch 2 Loop Input	8	Ch 2 Redundant Loop Input
K	Ch 2 Loop Input	9	Ch 2 Redundant Loop Input
L	Chassis Ground	10	Det. Address Bit #1 Ch 4 Timer Control Input
P	Ch 3 Loop Input	13	Ch 3 Redundant Loop Input
R	Ch 3 Loop Input	14	Ch 3 Redundant Loop Input
S	Ch 3 Output (+)	15	Det. Address Bit #2
T	Ch 3 Output (-)	16	Ch 3 Status Output
U	Ch 4 Loop Input	17	Ch 4 Redundant Loop Input
V	Ch 4 Loop Input	18	Ch 4 Redundant Loop Input
W	Ch 2 Output (+)	19	Data Trans. Output (TX)
X	Ch 2 Output (-)	20	Ch 2 Status Output
Y	Ch 4 Output (+)	21	Data Receive Input (RX)
Z	Ch 4 Output (+)	22	Ch 4 Status Output

Specifications subject to local environmental conditions, and may be subject to change. All Eberle Design LLC. products are Designed, Manufactured and Tested in the United States of America in facilities that are certified to ISO quality standards. DEFLECTOMETER, "Eberle Design Inc." and Eberle Design LLC. logo are trademarks of Eberle Design Inc. © 2024, Eberle Design LLC. Document: EDI_DATA_Oracle-Rack-Series_RevA